

Accessories for CEAST Impact Systems







CEAST Impact Systems Accessories

Second Edition



Table Of Contents

Drop Tower Accessories

Page 6

Optional Frame Features	9
Tup Holders	10
Tups and Inserts	13
Puncture Testing	17
CAI Testing	18
Pipe Testing	19
Tensile Impact Testing	20
Wedge Peel Testing	22
Component Testing	23
Charpy Testing	24
IZOD Testing	25

Pendulum Accessories	Page 26
Charpy Testing - Polymers (ISO, BS and DIN)	28
Charpy Testing - Polymers (ASTM)	30
Charpy Testing - Metals	31
IZOD Testing - Polymers	32
Pipe Testing - Polymers	34
Tensile Impact Testing - Polymers	36

Instrumentation and Software

Data Aquisition System	40
Visual Impact Software	41

Specimen Preparation

Notching Machines	44
Manual and Motorized Notchvis	44
Automatic Notchvis	45 - 46
Punching Machines	47

Appendix

Standards

Page 48

Page 38

Page 42

48



Drop Tower Accessories

The CEAST 9300 Series Drop Tower Impact Systems share the same state-of-the-art technology: reliability, safety, high-end technical specifications, and modularity. All models are designed to accomplish different testing needs whether the testing is performed on components or in accordance with a standard. The CEAST 9300 Series drop towers consist of the tabletop CEAST 9310, and the floor-standing CEAST 9340 and 9350. Frame options are available for retrofitting, including an anti-rebound system, environmental chambers, and loading systems. Various sizes and capacities of the tups and inserts can be fitted and changed. These accessories are available for many applications including puncture, compression after impact (CAI), tensile impact, and wedge peel testing.





Section	at	a	Gl	ar	ice

Optional Frame Features	9
Tup Holders	10
Tups and Inserts	13
Puncture Testing	17
CAI Testing	18
Pipe Testing	19
Tensile Impact Testing	20
Wedge Peel Testing	22
Component Testing	23
Charpy Testing	24
IZOD Testing	25

Page



	Description	9310	9340	9350
1	Anti-Rebound System	•	•	•
2	Environmental Chamber		•	•
	Additional Height		•	•
3	Additional Energy System			•
4	Pivoting Specimen Loader			•
5	Automatic Specimen Feeding System			•

Optional Frame Features

Anti-Rebound System

The absorbed kinetic energy of the falling crosshead can cause a rebound during drop events. The anti-rebound system prevents secondary impacts on the sample and can catch even the heaviest crosshead.

Environmental Chamber

Many components and materials are subjected to conditions above or below ambient temperatures. To simulate impact performance under these environmental conditions, the CEAST 9300 Series can be fitted with an environmental chamber, which cools specimens to -70 °C (-94 °F) or heats them up to 150 °C (302 °F). Air is circulated throughout the chamber, providing uniform temperature distribution to eliminate hot or cool spots.

Additional Height

We offer a steel base that lifts the drop tower by 300 mm (12 in). This extra height allows easier access to the test space.

Additional Energy System

This option increases the maximum energy of the CEAST 9350 system from 755 to 1800 Joules (1327.6 ft-lb). The spring-assisted velocity system accelerates the crosshead to increase the maximum impact energy with speeds up to 24 m/s (78.7 ft/s) with a 2 kg (4.4 lb) mass and 7 m/s (23 ft/s) with a 70 kg (154 lb) mass.

Pivoting Specimen Loader

The pivoting specimen loader can test up to 10 specimens in rapid sequence within the environmental chamber.

Automatic Specimen Feeding System *

The specimen feeding system performs tests in an automatic cycle within the environmental chamber and tests up to 120 samples per hour. This system is designed to meet the demand for automation where intensive, high-volume testing is required.

*Must be added with initial purchase. It cannot be added in the field.

Tup Holders

A range of tup holders and additional weight sets are available for the CEAST 9300 Series Drop Towers. Used to tailor the energy requirements to meet your needs, they reduce the minimum energy or add to the maximum energy available.

	Catalog Number	Description	Wei Rar	0		ergy nge	Maxi Ene		Velo Rar	2
			kg	lbs	J	ft-lbs	J	ft-lbs	m/s	ft/s
1	7520.022	Lightweight Tup Holder	2.0 to 5.0	4.4 to 11.0	0.59 to 54.0	0.44 to 39.8	833	614	0.77 to 4.65	2.53 to 15.3
9 350	7520.021	Standard Weight Tup Holder	5.0 to 30.0	11.0 to 66.0	1.47 to 329	1.08 to 243	1327	979	0.77 to 4.65	2.53 to 15.3
CEAST 9	7520.026	Additional Weight Set for Standard and Reinforced Tup Holders	Up to 70.0	154	Up to 757	558	1800	1330	0.77 to 4.65	2.53 to 15.3
	7520.935	Reinforced Tup Holder for 222 kN (50,000 lb) Tup	6.0 to 31.0	13.0 to 68.0	1.77 to 334	1.30 to 246	1327	979	0.77 to 4.65	2.53 to 15.3

Note: The weight range includes an average tup and insert weight of 0.7 kg (1.54 lbs) * With High-Energy System

	Catalog Number	Description		ight 1ge		ergy nge		nge
			kg	lbs	J	ft-lbs	m/s	ft/s
3	7510.022	Lightweight Tup Holder	1.0 to 3.5	1.20 to 7.72	0.30 to 37.8	0.21 to 27.9	0.77 to 4.65	2.53 to 15.3
CEAST 9340	7510.021	Standard Weight Tup Holder	3.0 to 22.5	6.61 to 49.6	0.88 to 243	0.65 to 179	0.77 to 4.65	2.53 to 15.3
Ğ	7510.026	Additional Weight Set for Standard Weight Tup Holder	37.5	82.7	405	299	0.77 to 4.65	2.53 to 15.3

Note: The weight range includes an average tup and insert weight of 0.5 kg (1.10 lbs)

	Catalog Number	Description		eight nge		ergy Inge		ocity Inge
0			kg	lbs	J	ft-lbs	m/s	ft/s
CEAST 931	n/a	Standard Tup Holder	0.5 to 3.00	1.10 to 6.83	0.15 to 21	0.11 to 15.49	0.77 to 3.7	2.53 to 12.14

Note: The weight range includes an average tup and insert weight of 0.2 kg (1.10 lbs)













Tups and Inserts

The tup is the heart of the drop tower; it's the piece that impacts the sample or component. This mechanical component comes in diverse shapes, sizes, and weights. Most tups can be purchased with sensors to perform instrumented impact tests, as well as interchangeable inserts (the head of the tup). The required capacity is dependent on the application and based on the expected maximum load, not the machine's energy capacity.

Instrumented Tups

Instrumented tups are designed with either a strain gauge or piezoelectric sensor embedded in the tup insert. These devices capture the impact and transform it into an electric signal, which is collected by a data acquisition system so the user can see a picture of the impact.

Instrumented tups are available in a range of shapes and sensors to comply with various testing standards.

Un-Instrumented Tups

Un-instrumented tups are used for tests where "break" or "no break" type results are required. These devices have a geometrical shape that is defined by a test standard. In cases where un-instrumented tups are designed to work with tensile-impact and adhesive-impact fixtures, the force sensor is installed in the application-specific fixture.

Strain Gauge Sensor

As the more robust tup inserts, strain gauge sensors are recommended for impact testing of materials that are made from composites, fail in a ductile mode, and are anticipated to have load values more than 5 kN (1124 lbs).

Piezoelectric Sensor

These higher-frequency tup inserts are ideal when testing fairly brittle or light-load materials, such as thin films.

Strain Gauge Tups and Inserts

45

90

	Catalog Number	Cap	pacity		sert Diameter turing Test)
~		kN	Ibs	mm	in
Tups	7529.301	22	5,000	10	0.394
e 1)	7529.302	45	10,000	20	0.787
(Type	7529.303	90	20,000	20	0.787
Gauge	7529.304	222	50,000	20	0.787
Ŭ	Catalog Number	Cap	pacity		sert Diameter turing Test)
bs		kN	Ibs	mm	in
-) Tups	7519.301	22	5,000	10	0.394

10,000

20,000

20

20

0.787

0.787

CEAST 9340 Strain Gauge (Type 1) Tups

Tup Inserts for Strain Gauge (Type 1) Tups

14

Catalog Number Description Testing Standards Tup Compatibility 7529.310 7519.310 10 mm (0.394 in) Ø Hemispherical ISO 6603-1,-2, ISO 7765-1,-2 7529.301 7519.310 10 mm (1/2 in) Ø Hemispherical ASTM D3763, ASTM D7192, ASTM 7529.301 7519.311 12.7 mm (1/2 in) Ø Hemispherical ASTM D3763, ASTM D7192, ASTM 7529.301 7529.313 20 mm (0.787 in) Ø Hemispherical ISO 6603-1,-2, ISO 7765-1,-2 ASTM D5628 Method FE 7529.320 10 mm (0.394 in) Ø Hemispherical ISO 6603-1,-2, ISO 7765-1,-2 ASTM D5628 Method FE 7529.321 12.7 mm (1/2 in) Ø Hemispherical ISO 6603-1,-2, ISO 7765-1,-2 ASTM D5628 Method FE 7529.321 12.7 mm (1/2 in) Ø Hemispherical ASTM D3763, ASTM D7192, ASTM Fe of Non-Puncturing Test) 7529.322 16 mm (5/8 in) Ø Hemispherical ASTM D7136/7136M, IsO 179.2 All Strain Gauge 7529.324 25.4 mm (1 in) Ø Hemispherical ASTM D5628 Method FE All Strain Gauge 7529.330 Plastics Charpy Insert ISO 179-2 Gauge 7529.332 Plastics Charpy Insert ISO 180, ASTM D256 (Type 1) 7529.333 <t< th=""><th></th><th></th><th></th><th></th></t<>				
10 mm (0.394 in) Ø Hemispherical ISO 6603-1,-2, ISO 7765-1,-2 7519.301 7529.311 12.7 mm (1/2 in) Ø Hemispherical ASTM D3763, ASTM D7192, ASTM D5628 Method FD 7529.301 7529.313 20 mm (0.787 in) Ø Hemispherical (For Non-Puncturing Test) ISO 6603-1,-2, ISO 7765-1,-2 ASTM D5628 Method FE 7519.301 7529.320 10 mm (0.394 in) Ø Hemispherical (For Non-Puncturing Test) ISO 6603-1,-2, ISO 7765-1,-2 ASTM D5628 Method FE 7529.321 7529.321 12.7 mm (1/2 in) Ø Hemispherical (For Non-Puncturing Test) ISO 6603-1,-2, ISO 7765-1,-2 ASTM D3763, ASTM D7192, ASTM D5628 Method FE 7529.322 16 mm (5/8 in) Ø Hemispherical (For Non-Puncturing Test) ASTM D7136/7136M, Airbus AITM 1.0010, PR-EN 6038, ISO 18352, Boeing BSS 7260, SACMA 2R-94 SACMA 2R-94 7529.324 25.4 mm (1 in) Ø Hemispherical (For Non-Puncturing Test) ASTM D5628 Method FC ASTM D5628 Method FB 7529.329 6.35 mm (1/4 in) Radius Conical, 25.4 mm Ø (1 in) Base ASTM D5628 Method FB AII Strain Gauge (Type 1) Tups 7529.330 Plastics Charpy Insert ISO 180, ASTM D256 Tups 7529.331 Plastics Charpy Insert ISO 180, ASTM D256 Tups 7529.335 Metals Charpy Insert, 8 mm Tip Radius ASTM D5115, EN 10045 </td <td>-</td> <td>Description</td> <td>0</td> <td>Tup Compatibility</td>	-	Description	0	Tup Compatibility
7519.310 7519.301 7529.311 12.7 mm (1/2 in) Ø Hemispherical ASTM D3763, ASTM D7192, ASTM D5628 Method FD 7529.301 7519.311 12.7 mm (1/2 in) Ø Hemispherical ISO 6603-1,-2, ISO 7765-1,-2 ASTM D5628 Method FE 7519.301 7529.313 20 mm (0.787 in) Ø Hemispherical (For Non-Puncturing Test) ISO 6603-1,-2, ISO 7765-1,-2 7529.320 7529.320 10 mm (0.394 in) Ø Hemispherical (For Non-Puncturing Test) ISO 6603-1,-2, ISO 7765-1,-2 7529.321 7529.321 12.7 mm (1/2 in) Ø Hemispherical (For Non-Puncturing Test) ASTM D3763, ASTM D7192, ASTM D5628 Method FD 7529.322 7529.322 16 mm (5/8 in) Ø Hemispherical (For Non-Puncturing Test) ASTM D7136/7136M, Airbus AITM 1.0010, PR-EN 6038, ISO 18352, Boeing BSS 7260, SACMA 2R-94 7529.324 25.4 mm (1 in) Ø Hemispherical ASTM D5628 Method FC 7529.329 6.35 mm (1/4 in) Radius Conical, 25.4 mm Ø (1 in) Base ASTM D5628 Method FB AII Strain Gauge (Type 1) Type 3) 7529.330 Plastics Charpy Insert ISO 180, ASTM D256 Tups 7529.331 Plastics Charpy Insert ASTM D6110 Tups 7529.332 Plastics Charpy Insert ISO 180, ASTM D256 Tups 7529.335 Metals Charpy Insert, 8 mm Tip Radius ASTM E23, ISO 148 Tups </td <td>7529.310</td> <td>40 mm (0.204 in) @ Uppring having l</td> <td></td> <td>7529.301</td>	7529.310	40 mm (0.204 in) @ Uppring having l		7529.301
12.7 mm (1/2 in) Ø Hemispherical ASIM D3/03, ASIM D1292, ASIM D5628 Method FD 7519.301 7519.311 20 mm (0.787 in) Ø Hemispherical ISO 6603-1,-2, ISO 7765-1,-2 ASTM D5628 Method FE 7519.301 7529.320 10 mm (0.394 in) Ø Hemispherical (For Non-Puncturing Test) ISO 6603-1,-2, ISO 7765-1,-2 ASTM D5628 Method FE 7529.320 7529.321 12.7 mm (1/2 in) Ø Hemispherical (For Non-Puncturing Test) ASTM D3763, ASTM D7192, ASTM D5628 Method FD 7529.321 7529.322 16 mm (5/8 in) Ø Hemispherical (For Non-Puncturing Test) ASTM D7136/7136M, Airbus AITM 1.0010, PR-EN 6038, ISO 18352, Boeing BSS 7260, SACMA 2R-94 ASTM D5628 Method FD 7529.324 25.4 mm (1 in) Ø Hemispherical (For Non-Puncturing Test) ASTM D5628 Method FC 7529.329 6.35 mm (1/4 in) Radius Conical, 25.4 mm Ø (1 in) Base ASTM D5628 Method FB 7529.330 Plastics Charpy Insert ISO 180, ASTM D256 7529.331 Plastics Charpy Insert ISO 180, ASTM D256 7529.332 Plastics Charpy Insert ISO 180, ISO 148 7529.335 Metals Charpy Insert, 2 mm Tip Radius ASTM D5115, EN 10045	7519.310	10 mm (0.394 in) Ø Hemispherical	150 6603-1,-2, 150 7765-1,-2	7519.301
7519.311 D5628 Method FD 7519.301 7529.313 20 mm (0.787 in) Ø Hemispherical (For Non-Puncturing Test) ISO 6603-1,-2, ISO 7765-1,-2 ASTM D5628 Method FE 150 6603-1,-2, ISO 7765-1,-2 7529.320 10 mm (0.394 in) Ø Hemispherical (For Non-Puncturing Test) ISO 6603-1,-2, ISO 7765-1,-2 150 7529.321 7529.321 12.7 mm (1/2 in) Ø Hemispherical (For Non-Puncturing Test) ASTM D3763, ASTM D7192, ASTM D5628 Method FD ASTM D7136/7136M, Airbus AITM 1.0010, PR-EN 6038, ISO 18352, Boeing BSS 7260, SACMA 2R-94 7529.322 16 mm (5/8 in) Ø Hemispherical (For Non-Puncturing Test) ASTM D5628 Method FC ASTM D5628 Method FC 7529.324 25.4 mm (1 in) Ø Hemispherical (So 179-2) - ASTM D5628 Method FB AII Strain Gauge (Type 1) 7529.330 Plastics Charpy Insert ISO 180, ASTM D51025 Tups 7529.331 Plastics Charpy Insert ISO 180, ASTM D256 Tups 7529.335 Metals Charpy Insert, 8 mm Tip Radius ASTM E23, ISO 148 Tups	7529.311		ASTM D3763, ASTM D7192, ASTM	7529.301
7529.313 20 mm (0.787 in) Ø Hemispherical (For Non-Puncturing Test) ASTM D5628 Method FE 7529.320 10 mm (0.394 in) Ø Hemispherical (For Non-Puncturing Test) ISO 6603-1,-2, ISO 7765-1,-2 7529.321 12.7 mm (1/2 in) Ø Hemispherical (For Non-Puncturing Test) ASTM D3763, ASTM D7192, ASTM D5628 Method FD 7529.321 16 mm (5/8 in) Ø Hemispherical (For Non-Puncturing Test) ASTM D7136/7136M, Airbus AITM 1.0010, PR-EN 6038, ISO 18352, Boeing BSS 7260, SACMA 2R-94 7529.324 25.4 mm (1 in) Ø Hemispherical (For Non-Puncturing Test) - 7529.325 38.1 mm (1.1/2 in) Ø Hemispherical (So 18352, Boeing BSS 7260, SACMA 2R-94 - 7529.329 6.35 mm (1/4 in) Radius Conical, 25.4 mm Ø (1 in) Base ASTM D5628 Method FC 7529.330 Plastics Charpy Insert ISO 179-2 7529.331 Plastics Charpy Insert ASTM D6110 7529.332 Plastics Charpy Insert ISO 180, ASTM D256 7529.335 Metals Charpy Insert, 8 mm Tip Radius ASTM E23, ISO 148 7529.336 Metals Charpy Insert, 2 mm Tip Radius ISO 148, DIN 50115, EN 10045	7519.311	12.7 mm (1/2 m) Ø Hernispherica	D5628 Method FD	7519.301
7529.320 (For Non-Puncturing Test) ISO 6603-1,-2, ISO 7765-1,-2 7529.321 12.7 mm (1/2 in) Ø Hemispherical (For Non-Puncturing Test) ASTM D3763, ASTM D7192, ASTM D5628 Method FD 7529.321 16 mm (5/8 in) Ø Hemispherical (For Non-Puncturing Test) ASTM D3763, ASTM D7192, ASTM D5628 Method FD 7529.322 16 mm (5/8 in) Ø Hemispherical (For Non-Puncturing Test) ASTM D3567136M, Airbus AITM 1.0010, PR-EN 6038, ISO 18352, Boeing BSS 7260, SACMA 2R-94 7529.324 25.4 mm (1 in) Ø Hemispherical - 7529.325 38.1 mm (1 1/2 in) Ø Hemispherical ASTM D5628 Method FC 7529.329 6.35 mm (1/4 in) Radius Conical, 25.4 mm Ø (1 in) Base ASTM D5628 Method FB 7529.330 Plastics Charpy Insert ISO 179-2 7529.331 Plastics Charpy Insert ASTM D6110 7529.332 Plastics Charpy Insert ISO 180, ASTM D256 7529.335 Metals Charpy Insert, 8 mm Tip Radius ASTM E23, ISO 148 7529.336 Metals Charpy Insert, 2 mm Tip Radius ISO 148, DIN 50115, EN 10045	7529.313	20 mm (0.787 in) Ø Hemispherical		
7529.321(For Non-Puncturing Test)D5628 Method FD7529.32216 mm (5/8 in) Ø Hemispherical (For Non-Puncturing Test)ASTM D7136/7136M, Airbus AITM 1.0010, PR-EN 6038, ISO 18352, Boeing BSS 7260, SACMA 2R-947529.32425.4 mm (1 in) Ø Hemispherical-7529.32538.1 mm (1 1/2 in) Ø HemisphericalASTM D5628 Method FC7529.3296.35 mm (1/4 in) Radius Conical, 25.4 mm Ø (1 in) BaseASTM D5628 Method FB7529.330Plastics Charpy InsertISO 179-27529.331Plastics Charpy InsertASTM D61107529.332Plastics Charpy InsertISO 180, ASTM D2567529.335Metals Charpy Insert, 8 mm Tip RadiusASTM E23, ISO 1487529.336Metals Charpy Insert, 2 mm Tip RadiusISO 148, DIN 50115, EN 10045	7529.320	· · · · ·	ISO 6603-1,-2, ISO 7765-1,-2	
7529.32216 mm (5/8 in) Ø Hemispherical (For Non-Puncturing Test)Airbus AITM 1.0010, PR-EN 6038, ISO 18352, Boeing BSS 7260, SACMA 2R-947529.32425.4 mm (1 in) Ø Hemispherical-7529.32538.1 mm (1 1/2 in) Ø HemisphericalASTM D5628 Method FC7529.3296.35 mm (1/4 in) Radius Conical, 25.4 mm Ø (1 in) BaseASTM D5628 Method FB7529.330Plastics Charpy InsertISO 179-27529.331Plastics Charpy InsertASTM D61107529.332Plastics Charpy InsertISO 180, ASTM D2567529.335Metals Charpy Insert, 8 mm Tip RadiusASTM E23, ISO 1487529.336Metals Charpy Insert, 2 mm Tip RadiusISO 148, DIN 50115, EN 10045	7529.321		, , ,	
7529.32538.1 mm (1 1/2 in) Ø HemisphericalASTM D5628 Method FC7529.3296.35 mm (1/4 in) Radius Conical, 25.4 mm Ø (1 in) BaseASTM D5628 Method FB7529.330Plastics Charpy InsertISO 179-27529.331Plastics Charpy InsertASTM D61107529.332Plastics Charpy InsertISO 180, ASTM D2567529.335Metals Charpy Insert, 8 mm Tip RadiusASTM E23, ISO 1487529.336Metals Charpy Insert, 2 mm Tip RadiusISO 148, DIN 50115, EN 10045	7529.322		Airbus AITM 1.0010, PR-EN 6038, ISO 18352, Boeing BSS 7260,	
7529.331Plastics Charpy InsertASTM D6110(Type 1) Tups7529.332Plastics Charpy InsertISO 180, ASTM D2567529.335Metals Charpy Insert, 8 mm Tip RadiusASTM E23, ISO 1487529.336Metals Charpy Insert, 2 mm Tip RadiusISO 148, DIN 50115, EN 10045	7529.324	25.4 mm (1 in) Ø Hemispherical	-	
7529.331Plastics Charpy InsertASTM D6110(Type 1) Tups7529.332Plastics Charpy InsertISO 180, ASTM D2567529.335Metals Charpy Insert, 8 mm Tip RadiusASTM E23, ISO 1487529.336Metals Charpy Insert, 2 mm Tip RadiusISO 148, DIN 50115, EN 10045	7529.325	38.1 mm (1 1/2 in) Ø Hemispherical	ASTM D5628 Method FC	
7529.331Plastics Charpy InsertASTM D6110(Type 1) Tups7529.332Plastics Charpy InsertISO 180, ASTM D2567529.335Metals Charpy Insert, 8 mm Tip RadiusASTM E23, ISO 1487529.336Metals Charpy Insert, 2 mm Tip RadiusISO 148, DIN 50115, EN 10045	7529.329		ASTM D5628 Method FB	All Strain
7529.331Plastics Charpy InsertASTM D6110Tups7529.332Plastics Charpy InsertISO 180, ASTM D2567529.335Metals Charpy Insert, 8 mm Tip RadiusASTM E23, ISO 1487529.336Metals Charpy Insert, 2 mm Tip RadiusISO 148, DIN 50115, EN 10045	7529.330	Plastics Charpy Insert	ISO 179-2	0
7529.335Metals Charpy Insert, 8 mm Tip RadiusASTM E23, ISO 1487529.336Metals Charpy Insert, 2 mm Tip RadiusISO 148, DIN 50115, EN 10045	7529.331	Plastics Charpy Insert	ASTM D6110	
7529.336 Metals Charpy Insert, 2 mm Tip Radius ISO 148, DIN 50115, EN 10045	7529.332	Plastics Charpy Insert	ISO 180, ASTM D256	
	7529.335	Metals Charpy Insert, 8 mm Tip Radius	ASTM E23, ISO 148	
7529.337 Metals IZOD Insert ASTM E23	7529.336	Metals Charpy Insert, 2 mm Tip Radius	ISO 148, DIN 50115, EN 10045	
	7529.337	Metals IZOD Insert	ASTM E23	
7529.340 Metals DWTT Insert ASTM E208	7529.340	Metals DWTT Insert	ASTM E208	
7529.350 50 mm Ø Flat Faced -	7529.350	50 mm Ø Flat Faced	-	
7529.360 12.7 mm (1/2 in) Radius Conical, 50.8 mm Ø (2 in) Base ASTM D2444 - Type A	7529.360		ASTM D2444 - Type A	
7529.361 50.8 mm (2 in) Radius Conical, 50.8 mm Ø (2 in) Base ASTM D2444 - Type B	7529.361		ASTM D2444 - Type B	
7529.362 12.7 mm (1/4 in) Radius Conical, 50.8 mm Ø (2 in) Base ASTM D2444 - Type C	7529.362		ASTM D2444 - Type C	

Piezo Tups and Inserts Minimum

	Catalog Number		Capacity	Minimum Insert Diameter		
		kN	lbs	mm	in	
CEAST 9350 Piezo (Type 2) Tups	7529.694	4.5	1,000	12.7	0.50	
	7529.696	22	5,000	12.7	0.50	
335C	7529.601	0.4	5 100	20	0.787	
AST 9350 Pie (Type 2) Tups	7529.604	4.5	1,000	20	0.787	
8 -	7529.606	22	5,000	20	0.787	
	Catalog Number		Capacity	Minimum Insert Diame	ter	
		kN	lbs	mm	in	
8	7519.694	4.5	1,000	12.7	0.50	
Piez ups	7519.696	22	5,000	12.7	0.50	
934C	7519.601	0.4	5 100	20	0.787	
CEAST 9340 Piezo (Type 2) Tups	7519.604	4.5	1,000	20	0.787	
8 -	7519.606	22	5,000	20	0.787	
	Catalog Number	Tup Adapter	Description	Standards	Tup Compatibility	
	7529.801	-	12.7 mm (1/2 in) Ø Hemispherical	ASTM D3763, ASTM D7192, ASTM D5628 Method FD	7529.694 7519.694	
	7529.802	-	12.7 mm (1/2 in) Ø Hemispherical	ASTM D3763, ASTM D7192, ASTM D5628 Method FD	7529.696 7519.696	
	7529.803	-	15.875 mm (5/8 in) Ø Hemispherical	ASTM D35628 Method FA	7529.694 7519.694 7529.696 7519.696	
biezo s	7529.825	-	16 mm (5/8 in) Ø Hemispherical	ASTM D7136/7136M, Airbus AITM 1.0010, PR-EN 6038, ISO 18352, Register S25	7529.694 7519.694 7529.696 7519.696	
Inserts for Pie (Type 2) Tups	7529.826		16 mm (5/8 in) Ø Hemispherical (For non-puncturing test)	Boeing BSS 7260, SACMA 2R-94		
Tup Inserts for Piezo (Type 2) Tups	7529.804	7529.894	20 mm (0.787 in) Ø Hemispherical	ISO 6603-1,-2, ISO 7765-1,-2, ASTM D5628 Method FE		
	7529.830		50mm Ø Flat Faced	-		
	7529.806		25.4 mm (1 in) Ø Hemispherical	-	All Piezo	
	7529.840	7529.896	6.35 mm (1/4 in) Radius Conical, 25.4 mm Ø (1 in) Ø Base	ASTM D5628 Method FB	(Type 2) Tups	
	7529.807	7529.897	38.1 mm (1/2 in) Ø Hemispherical	ASTM D5628 Method FC		
	7529.812		Plastic Charpy Insert	ISO 179-2		
	7529.811	7529.894	Plastic Charpy Insert	ASTM D6110		
	7529.810	1020.004	Plastics IZOD Insert	ISO 180, ASTM D256		

www.instron.com/accessories 15



Test fixtures, a key component of the CEAST 9300 Series Drop Towers, are designed to test to a wide range of standards, components, and products. The fixture set includes a stand, where the specimen rests, and clamping mechanisms that push the specimen against the stand and hold it securely in place during an impact test.

Fixed-Height Stand - 7520.031

The fixed-height stand positions each sample so that a tup strikes it during an impact test. The design accommodates specimens with a thickness up to 25 mm (1 in), making it an ideal solution for testing films and plates. It can also be used for Charpy and Izod tests.

2 Adjustable Height Stand - 7520.035

This stand is equipped with a flexible base that can travel 100 mm (3.9 in) through simple, screw-action adjustments. This adjustable design accommodates specimens with a thickness up to 195 mm (7.67 in), making it an ideal solution for films, plates, tubes, and components. It can also be used for both Charpy and Izod tests in combination with adapter 7520.039.

Puncture Testing

Clamping plates for the CEAST 9350 and CEAST 9340 use a pneumatic system to push the sample against the test stand, holding it securely in place during the impact test. For the CEAST 9310, clamps are manually operated. Customized plates are available upon request.



	Catalog Number	Clampi Diamet	0	Testing Standards	Compatible Stands
		mm	in		
Plastics 3T 9340	7520.041	38.10	1.50	ASTM D5628 Geometry FB	
Rigid Plas I CEAST 9	7520.042	40.00	1.57	ISO 6603-1, ISO 6603-2 and ASTM D5628 Geometry FE	_
for F and	7520.043	76.00	3.00	ASTM D3763, ASTM D5628 Geometry FA and FD	7520.031 or 7520.035
Plates 9350 a	7520.044	100.00	3.94	ISO 6603-1 and ISO 6603-2	and
ping EAST	7520.046	127.00	5.00	ASTM D5628 Geometry FC	7520.039
Clamping on CEAST	7520.056	32.00 (internal)	1.26	Montell Method MA 17238	
0.0	7520.056	39.00 (external)	1.54	WORLEN WELHOU MA 1/238	

Catalog Number	Clamping Diameter		Testing Standards	Compatible Stands	Clamping Surface
	mm	in			
7520.050	40.00	1.57	ISO 7765-2		Undulated
7520.054	40.00	1.57	ISO 7765-2	7520.031	Rubber
7520.051	76.00	3.00	ASTM D3763	0r 7500.025	Rubber
7520.052	125.00	4.92	ISO 7765-1	7520.035 and 7520.039	Rubber
7520.053	127.00	5.00	ASTM D1709		Rubber
7520.055	100.00	3.94	-		Rubber

Catalog Number	Clamping Diameter		Testing Standards
	mm	in	
6887.050	40.00	1.57	ISO 7765-2
6887.051	76.00	3.00	ASTM D3763
6887.052	127.00	5.00	ASTM D1709

CAI Testing

Compression After Impact (CAI) testing is common for composite materials and standards including Boeing BMS-7260, SACMA 2R-94, ASTM D7136/M, and Airbus AITM 1.0010. The fixture and insert varies for each test, and the crosshead weight is very important. The anti-rebound system is required for all standards, while a tup and insert are required to complete the configuration and must be chosen based on the expected maximum load.

Catalog Number	Description		Window Size		imen ze	Testing Standards
		mm	in	mm	in	
7520.350	CAI Impact Fixture, Metric (Aluminum Top Plate)	75.0 × 125.0	2.95 × 4.92	100.0 × 150.0	3.94 × 5.91	ASTM D7136M
7520.351	CAI Impact Fixture, Imperial (Aluminum Top Plate)	76.2 × 127.0	3.00 × 5.00	101.6 × 152.4	4.00 × 6.00	ASTM D7136 SACMA 2R-94
7520.352	CAI Impact Fixture, Metric (Steel Top Plate)	75.0 × 125.0	2.95 × 4.92	100.0 × 150.0	3.94 × 5.91	ASTM D7136M, Airbus AITM 1.0010, PR-EN 6038, ISO 18352
7520.353	CAI Impact Fixture, Imperial (Steel Top Plate)	76.2 × 127.0	3.00 × 5.00	101.6 × 152.4	4.00 × 6.00	ASTM D7136, Boeing BSS 7260 Class II



CAI Testing Fixtures for CEAST 9350 and CEAST 9340

Pipe Testing

Our pipe testing fixtures feature a V-grooved design to hold cylindrical specimens up to 160 mm (6.30 in) and it complies with ASTM D2444. A tup and insert are required to complete the configuration and must be chosen based on the expected maximum load.

H	Catalog Number	Specimen Size		Testing Standards	Compatible Stands
CEAST 40		mm	in		
93, 10	7520.210	25.0 to 65.0	0.98 to 2.56	ASTM D2444	7520.035
Fixtures d CEAST	2 7520.212 80.0 to 160.0		3.15 to 6.30 ASTM D2444		7520.035
⊳	3 7520.215	Small Pipes and Fittings		ASTM D2444 Type B	7520.035 and 7520.039






Tensile Impact Testing

This instrumented vice is designed to meet ISO 8256 A for tensile impact tests. The fixture is suitable for specimen types 1-2-3-4-5 and equivalents, and includes fixed-height vice supports. The complete fixture requires the selection of a piezoelectric force sensor, a clamping device, and a vice.

Catalog Number	Description	Testing Standard
1 7520.250	Instrumented Vice for ISO 8256 A Tensile Impact Tests	ISO 8256 A
2 7520.251	Piezoelectric Force Sensor 2.2 kN	ISO 8256 A
2 7520.252	Piezoelectric Force Sensor 0.45 kN	ISO 8256 A
7520.255	Clamping for Rigid and Film Specimens Types 1 and 3	ISO 8256 A
3 7520.256	Clamping for Rigid and Film Specimens Types 2 and 4	ISO 8256 A
7520.257	Clamping for Rigid Specimens Type 5	ISO 8256 A
4 7520.260	Striker for ISO 8256 A Tensile Impact Test (CEAST 9350)	ISO 8256 A
4 7510.260	Striker for ISO 8256 A Tensile Impact Test (CEAST 9340)	ISO 8256 A
5 7520.271	Tensile Grips - 30 g for Rigid Specimen Types 1, 2, 3 and 4	ISO 8256 A
7520.272	Tensile Grips - 60 g for Rigid Specimen Types 1, 2, 3 and 4	ISO 8256 A
7520.273	Tensile Grips - 120 g for Rigid Specimen Types 1, 2, 3 and 4	ISO 8256 A
7520.276	Tensile Grips - 30 g for Rigid Specimen Type 5	ISO 8256 A
7520.277	Tensile Grips - 60 g for Rigid Specimen Type 5	ISO 8256 A
7520.278	Tensile Grips - 120 g for Rigid Specimen Type 5	ISO 8256 A
7520.281	Tensile Grips - 30 g for Film Specimens Type 1, 2, 3 and 4	ISO 8256 A
7520.282	Tensile Grips - 60 g for Film Specimens Type 1, 2, 3 and 4	ISO 8256 A
7520.283	Tensile Grips - 120 g for Film Specimens Type 1, 2, 3 and 4	ISO 8256 A







Wedge Peel Testing

The impact wedge peel test is an ISO test method used to measure the resistance of structural adhesives to cleavage fracture at various temperatures and test speeds of 2 and 3 m/s. This common test is used in both the development of new adhesives and the quality control of product batches.



934C		Catalog Number	Description	Testing Standard
CEAST	1	7520.304	Support Stand, Clamp and 15 kN Strain Gauge Sensor for ISO 11343	ISO 11343
7 9350 and		7520.305	Symmetric Wedge	ISO 11343
for CEAS1	2	7520.306	Asymmetric Wedge	ISO 11343
Peel Accessories for CEAST	3	7520.310	Striker for ISO 11343 Testing (CEAST 9350)	ISO 11343
ge Peel Ac	3	7510.310	Striker for ISO 11343 Testing (CEAST 9340)	ISO 11343
Wedge				

Component Testing

Fixtures can be custom designed to test a wide variety of uniquely sized parts and components. Please ask about options for your application if a standard product is not available.




	Catalog Number Description		S	ize	Compatible Stands
			mm	in	
4	7520.037	General Purpose Plate Stand Mounted	275 × 275	10.83 × 10.83	7520.035
	7520.020	General Purpose T-Slot Plate Stand Mounted	370 × 450	14.57 × 17.72	7520.055
5	7520.040	General Purpose T-Slot Plate Base Mounted	570 × 450	14.57 ^ 11.72	Mounted on Base

Charpy Testing

Fixtures are available for testing to ASTM D6110 (formerly ASTM D256), ISO 179, and ASTM E23 Charpy standards. The tup chosen is based on the maximum load expected and is not related to the energy absorbed by the sample.

	Testing Standards	Specim	en Size	Sp	an	Vice	Shoulders	Stands
		mm	in	mm	in			
Charpy Testing accessories for CEAST 9350 and CEAST 9340	ISO 179						7520.063 (Flatwise)	
		4 × 10 × 80	.0 × 80 1.57	62	2.44	7520.064 (Edgewise) 7520.060 7520.066		
	ASTM D6110	3.17 × 12.7 × 127	0.125 × 0.50 × 5.00	101.6	4.00		10	7520.031 or 7520.035
		6.35 × 12.7 × 127	0.25 × 0.50 × 5.00	101.6	4.00		7520.066	and 7520.039
		12.7 × 12.7 × 127	0.50 × 0.50 × 5.00	101.6	4.00			
	ASTM E23	10 × 10 × 55	0.39 × 0.39 × 2.17	40	1.57		7520.069	



IZOD Testing

Fixtures are available for testing plastics to ASTM D256 and ISO 180 Izod standards.



	Standard	Specimen Size		Vice	Specimen Adapter	Stands
		mm	in			
	ISO 180	4 × 10 × 80	0.16 × 0.39 × 3.15	7520.080	6545.250	
		3.17 × 12.7 × 127	0.125 × 0.50 × 5.00	7520.080		7520.031
	ASTM D6110	6.35 × 12.7 × 127	0.25 × 0.50 × 5.00	7520.080	6545.051 6545.050 6545.124	or 7520.035
		12.7 × 12.7 × 127	0.50 × 0.50 × 5.00	7520.080		and 7520.039
	ASTM E23	10 × 10 × 55	0.39 × 0.39 × 2.17	7520.081	7520.089	



Pendulum Accessories

The CEAST 9000 Series Pendulum Impact Systems are designed to test a wide range of samples, from bars/dumbbell to pipes, in accordance with specific standards. The CEAST 9050 is the advanced model of the series. It can be fitted with accessories for Charpy, IZOD, Pipe, and Tensile Impact Testing. Each test requires a specific vice/fixture, specimen adapters, and hammers, and most tests can be conducted either with an un-instrumented or instrumented hammer.





Section at a Glance

Charpy Testing - Polymers (ISO, BS, and DIN)	28
Charpy Testing - Polymers (ASTM)	30
Charpy Testing - Metals	31
IZOD Testing - Polymers	32
Pipe Testing - Polymers	34
Tensile Impact Testing	36

Page

Charpy Testing | Polymers (ISO, BS, and DIN)

Accessories are available for ISO 179, BS 2782-359, DIN 53453, and DIN 53753. Since the hammer energy determines the velocity of test, the vice required and the shoulders should be chosen based on the specimen size. Samples are aligned on the fixture either by a notch alignment device or side alignment device for un-notched specimens. Instrumented hammers are available and, when combined with a DAS and Visual Impact software, will provide load-displacement data for the test.





	Catalog Number	Imp Velo		Alignment Device	Wooden Case	Testing Standards
		m/s	ft/s			
Charpy Vices Polymers (ISO, BS, and DIN)	7610.101	2.9	9.5	7610.112 (Notch)*, 7610.121 (Unnotched, 33-80 mm), 7610.122 (Unnotched. 80-127 mm)	7610.107	ISO 179-1,
	7610.102	3.8	12.5	7610.112 (Notch)*, 7610.121 (Unnotched, 33-80 mm), 7610.122 (Unnotched. 80-127 mm)	7610.108	ISO 179-2, BS 2782-359 DIN 53453 and
	7610.103	2.9 and 3.8	9.5 and 12.5	7610.113 (Notch)*, 7610.121 (Unnotched, 33-80 mm), 7610.122 (Unnotched. 80-127 mm)	7610.107	DIN 53753

* If used in combination with Cryobox Notch alignment device must be code 7610.115.

Catalog Number		cimen ensions	Sp	ban	Test Direction	Testing Standards
	mm in		mm	in		
7610.130	4 × 10 × 80	0.16 × 0.39	62	2.44	Flatwise	
7610.131	4 * 10 * 80	× 3.15	62	2.44	Edgewise	ISO 179-1,
7610.140	3 × 15 ×	0.12 × 0.59 ×			Edgewise	ISO 179-2
7610.150	33-39-75	1.30-1.54-2.95	18-24-60	0.71-0.94 -2.36	Flatwise	and BS 2782-
7610.145	3 × 10 ×	0.12 × 0.39 ×	(Adjustable)	(Adjustable)	Edgewise	359
7610.155	33-39-75	1.30-1.54-2.95			Flatwise	
7610.180	4 × 6 × 50	0.16 × 0.24 × 1.97	42	1.65	Flatwise	DIN 53453 and DIN 53753
7610.181	10 × 15 ×	0.39 × 0.59	72	2.83	Flatwise	DIN 53453
7610.182	120	× 4.72	12	2.03	Edgewise	DIN 55455

Catalog Number		Hammer ergy		oact ocity	Testing Standards		
	J	ft/lb	m/s ft/s				
7600.065	0.5	0.37	2.9	9.5			
7600.001	1.0	0.74	2.9	9.5			
7600.002	2.0	1.48	2.9	9.5			
7600.004	4.0	2.95	2.9	9.5	ISO 179-1, DIN 53453,		
7600.005	5.0	3.69	2.9	9.5	DIN 53753		
7600.007	7.5	5.53	3.8	12.5	and BS 2782-359		
7600.015	15.0	11.06	3.8	12.5			
7600.025			3.8	12.5			
7600.050			3.8	12.5			

	Catalog Number		Hammer ergy		Load Capacity		oact ocity	Connection Type	Testing Standards
		J	ft/lb	kN	lbs	m/s	ft/s		
and	7601.005.1(C)	5.0	3.69	2	450	2.9	9.5		ISO 179-2
sg 🙎	7601.007.1(C)	7.5	5.53	2	450	3.8	12.5	Slip Ring (Cable)	ISO 179-2
(ISO,	7601.015.1(C)	15.0	11.06	2	450	3.8	12.5		ISO 179-2
	7601.025.2(C)	25.0	18.44	4	900	3.8	12.5		ISO 179-2
olymers	7601.050.2(C)	50.0	36.89	4	900	3.8	12.5		ISO 179-2

Charpy Testing | Polymers (ASTM)

The vice, shoulders, and hammers listed here are designed to meet ASTM D6110. The test is conducted at 3.46 m/s (11.45 ft/s) and various hammer energies and specimen shoulders are available.

Ê	Catalog Number	Impact Velocity		Alignment Device	Wooden Case	Testing Standards
STIV		m/s	ft/s			
Charpy Vice Polymers (ASTM)	7610.105	3.46	11.35	7610.111 (Notch)*, 7610.122 (Unnotched, 80-127 mm)	7610.108	ASTM D6110
Poly	* If used in comb	ination wit	h Cryobox N	Notch alignment device must be code 761	LO.115.	

	Catalog Number	Spec Dimer		an	Test Direction	Testing Standards	
ders TM)		mm	in	mm	In		
(AS	7610.160	3.17 × 12.7 × 127	0.125 × 0.5 × 5.0	101.6	4.0	Edgewise	ASTM D6110
py SI mers	7610.161	6.35 × 12.7 × 127	0.25 × 0.5 × 5.0	101.6	4.0	Edgewise	ASTM D6110
Charpy Shoulders Polymers (ASTM)	7610.162	12.7 × 12.7 × 127	0.50 × 0.5 × 5.0	101.6	4.0	Edgewise	ASTM D6110

	Catalog Number	Potential Ene			pact pocity	Testing Standards
		J	ft/lb	m/s	ft/s	
×Ê	7600.165	0.5	50.0	3.46	11.35	ASTM D6110
un-instrumented Charpy Hammers Polymers (ASTM)	7600.101	1.0	0.74	3.46	11.35	ASTM D6110
ed C	7600.102	2.7	2.0	3.46	11.35	ASTM D6110
olym	7600.105	5.4	4.0	3.46	11.35	ASTM D6110
ers P	7600.110	10.8	8.0	3.46	11.35	ASTM D6110
u nu	7600.121	21.6	16.0	3.46	11.35	ASTM D6110
На	7600.150	50.0	36.9	3.46	11.35	ASTM D6110

Ξ.	Catalog Number	Potential Hammer Energy		Load Capacity		Impact Velocity		Connection Type	Testing Standards
(ASTI		J	ft/lb	kN	Ibs	m/s	ft/s		
	7601.105.1 (C)	5.4	4.0	2	450	3.46	11.35		ASTM D6110
Polymers	7601.110.1 (C)	10.8	8.0	2	450	3.46	11.35	Slip Ring	ASTM D6110
	7601.121.2 (C)	21.6	16.0	4	900	3.46	11.35	(Cable)	ASTM D6110
ammers	7601.150.2 (C)	50.0	36.9	4	900	3.46	11.35		ASTM D6110

Iln-Instrumented Charny

Instrumented Charpy Hammers Polymers (ASTM)

Charpy Testing | Metals

Accessories are available for metals Charpy Testing. Tests can be conducted to ASTM E23, ISO 148, and DIN 50115 with hammer energies up to 50 J.

	Catalog Number	Impact Velocity		Alignment Device	Wooden Case	Testing Standards
-		m/s ft/s				
	610107 38 175		7610.112 (Notch)*, 7610.121 (Unnotched, 33-80 mm)	7610.108	ASTM E23, ISO 148, and DIN 50115	

For indirect verification to metals standards only low-energy specimens may be used. * If used in combination with Cryobox Notch alignment device must be code 7610.115.

Catalog Number		pecimen mensions	S	pan	Test Direction	Testing Standards
	mm	in	mm	In		
7610.197	10 × 10 × 55	0.394 × 0.394 × 2.17	42	1.65	Edgewise	
7910.191	10 × 7.5 × 55	0.394 × 0.295 × 2.17	42	1.65	Edgewise	ASTM E23,
7610.192	10 × 5 × 55	0.394 × 0.197 × 2.17	42	1.65	Edgewise	ISO 148, and DIN
7610.193	10 × 2.5 × 55	0.394 × 0.098 × 2.17	42	1.65	Edgewise	50115
7610.194	5 × 5 × 55	0.197 × 0.197 × 2.17	42	1.65	Edgewise	
7610.195	4 × 3 × 27	0.157 × 0.118 × 1.06	24	0.945	Edgewise	DIN 50115
7610.196	6 × 6 × 44	0.236 × 0.236 × 1.73	32	1.26	Edgewise	DIN 50115

For indirect verification to metals standards only low-energy specimens may be used.

Instrumented Charpy Hammers - Metals

Charpy Vice Polymers (ASTM)

Charpy Shoulders Metals

	Catalog Number		Hammer ergy		iker dius		pact ocity	Testing Standards
		J	ft/lb	mm	in	m/s	ft/s	
,	7600.650	50.0	36.9	8	0.314	3.8	12.5	ISO 148 and ASTM E23
	7600.651	50.0	36.9	2	0.079	3.8	12.5	ISO 148 and DIN 50115

For indirect verification to metals standards only low-energy specimens may be used.

Catalog Number	Potential Hammer Energy		Load Capacity		Striker Radius		Impact Velocity		Connection Type	Testing Standards
	J	ft/lb	kN	lbs	mm	in	m/s	ft/s		
7601.650.1 (C)	50.0	36.9	8	1800	8	0.314	3.8	12.5	Slip Ring	ISO 148 and ASTM E23
7601.651.1 (C)	50.0	36.9	8	1800	2	0.079	3.8	12.5	(Cable)	ISO 148 and DIN 50115

For indirect verification to metals standards only low-energy specimens may be used.

IZOD Testing | Polymers

An IZOD test consists of impacting a specimen in a cantilever bending mode while the fixed end is clamped in a vice. This method gives a higher stress than a Charpy test, but may require a controlled clamping force for good repeatability. The manual vice can be tightened using the optional torque wrench (7610.204), while the clamping force can be adjusted using the lever or pneumatically-operated vices. Instrumented hammers are available and, when combined with a DAS and Visual Impact Software, will provide load-displacement data for the test.



	Catalog Number	Impact Velocity		Clamping Type	Alignment Device	Wooden Case	Testing Standards
		m/s	ft/s				
le Impact Vice	7610.201	3.46	11.35	Manual or Torque wrench	Notched (Included),	7610.108	ISO 180,
le Im Vice	7610.210	3.46	11.35	Lever Operated	Unnotched ISO 180 (7610.206),	-	ASTM D256, and
Tensi	7610.220	3.46	11.35	Pneumatic	Unnotched ASTM D256 (7610.205)	-	ASTM D4812

	Catalog Number	Specir Dimens	Testing Standards	
		mm	in	
<u>و</u> 2	6545.250	4 × 10 × 80	0.16 × 0.39 × 3.15	ISO 180
IZOD Specimen Adapters - Polymer	6545.409	3 × 10 × 80	0.12 × 0.39 × 3.15	ISO 180
	6545.051	3.17 × 12.7 × 63.5	0.125 × 0.50 × 2.50	ASTM D256
	6545.050	6.35 × 12.7 × 63.5	0.25 × 0.50 × 2.50	and
	6545.124	12.7 × 12.7 × 63.5	0.50 × 0.50 × 2.50	ASTM D4812



Catalog Number	Potential Hammer Energy			oact ocity	Testing Standards
	J	ft/lb	m/s	ft/s	
7600.265	0.5	0.37	3.46	11.35	
7600.201	1.0	0.74	3.46	11.35	
7600.202	2.75	2.0	3.46	11.35	ISO 180
7600.205	5.5	4.0	3.46	11.35	ASTM D256
7600.211	11.0	8.1	3.46	11.35	ASTM D4812
7600.222	22.0	16.0	3.46	11.35	
7600.250	50.0	36.89	3.46	11.35	

	Catalog Number		ad acity	Potential Hammer Energy		Impact Velocity		Connection Type	Testing Standards
		kN	lbs	J	ft/lb	m/s	ft/s		
Polymers	7601.205.1(C)	2	450	5.0	3.69	3.46	11.35		
- Pol	7601.211.1(C)	2	450	11.0	8.1	3.46	11.35	Slip Ring	ISO 180 ASTM D256
ers .	7601.222.1(C)	2	450	22.0	16.0	3.46	11.35	(Cable)	ASTM D4812
ammers	7601.250.1(C)	2	450	50.0	36.89	3.46	11.35		DIGIZ


Un-Instrumented IZOD Hammers - Polymers

Instrumented IZOD Hammers - Polymers



Pipe Testing | Polymers

According to ISO 7628 and ISO 9854, either complete segments or small sections of pipes are ideal for testing on a pendulum in a 3-point bend configuration similar to the Charpy tests. Sample diameter dimensions up to 25 mm (0.98 in) can be tested with hammer energies of 7.5 - 15 J (5.6 - 11.1 ft-lbs) or 50 J (36.9 ft-lbs), as defined in the ISO standards.



e	Catalog Number		Impact Velocity		Testing Standards
lg Vice		m/s	ft/s		
Testir	7610.740	3.8	12.5	7610.110	ISO 9854-1
Pipe T					

	Catalog Number	6			an	Specimen Type	Testing Standards
		mm	in	mm	in		
Adapters	6546.746	Complete Diameter <25 120 × 15 Diameter >25	Complete Diameter <0.98 4.72 × 0.59 Diameter >0.98	70	2.76	Fig. 1, Shape 1 and 3	ISO 9854-1
ing Ada	6546.747	50 × 6, Diameter >25	1.97 × 0.24, Diameter >0.98	40	1.57	Fig. 2, Shape 2	ISO 9854-1
Pipe Testing	6546.748	120 × 15, Diameter >75	4.72 × 0.59, Diameter >2.95	70	2.76	Fig. 3, Shape 3	ISO 9854-1
Ē	6546.749	50 × 6, Diameter >75	1.97 × 0.24, Diameter >2.95	40	1.57	Fig. 3, Shape 2	ISO 9854-1

	Catalog Number	Potential Hammer Energy		Imp Velo	Testing Standards	
Jerse		J	ft/lb	m/s	ft/s	
amn	7600.715	15.0	11.06	3.8	12.5	ISO 9854-1
ing H	7600.750	50.0	36.89	3.8	12.5	ASTM D4812

Tensile Impact Testing | Polymers

Hammer geometry, impact energy, specimen shapes, and dimensions are defined in test standards, such as ISO 8256 Method A and Method B. The specimen is either held in the stationary anvil (ISO 8256 Method A) or attached directly to the pendulum hammer (ISO 8256 Method B). Hammer energies are available from 0.5 - 50 J (0.37 - 36.9 ft-lbs) depending on the type of the test. The Tensile Impact Vice can be fitted in the crosshead with an optional device to ensure specimen alignment.



Catalog Number	Description	Testing Standards
7610.040	Crosshead Clamping Jig	ISO 8256 - Method A
7610.341	Tensile Impact Template, Specimen Type 1	ISO 8256 - Method A
7610.342	Tensile Impact Template, Specimen Type 2	ISO 8256 - Method A
7610.343	Tensile Impact Template, Specimen Type 3	ISO 8256 - Method A
7610.344	Tensile Impact Template, Specimen Type 4	ISO 8256 - Method A

Catalog Number	Potential Hammer Energy		Impact Velocity		Testing Standards
	J	ft/lb	m/s	ft/s	
7600.365	0.5	0.37	2.9	9.5	ISO 8256 - Method A
7600.301	1.0	0.74	2.9	9.5	ISO 8256 - Method A
7600.302	2.0	1.48	2.9	9.5	ISO 8256 - Method A
7600.304	4.0	2.95	2.9	9.5	ISO 8256 - Method A
7600.307	7.5	5.53	3.8	12.5	ISO 8256 - Method A
7600.315	15.0	11.06	3.8	12.5	ISO 8256 - Method A
7600.325	25.0	18.44	3.8	12.5	ISO 8256 - Method A
7600.350	50.0	36.89	3.8	12.5	ISO 8256 - Method A

Tensile Impact Hammers

	Catalog Number	Impact Velocity			Ener		Wooden C	ase	Testing Standards	
		m/s ft,	/s	J		ft/lb				
Fensile Impact Vice	7610.304	-	-	-		-				
Vice	7610.300	3.8 12	2.5	>5		>3.69	7610.10)9	ISO 8256 - Method A	
Lens 2	7610.301	2.9 9	.5	Up to 5		Up to 3.69			mothodire	
e	Catalog Number	Specimen Types				Specimer Thicknes			Testing Standards	
Tens ps				mm			in			
istrumented Tei Impact Clamps	7610.355	1, 2, 3 and 4	4	0.5 to 4	4.2		0.020 to 0.17			
umei act (7610.356	5		3.0 to 4	3.0 to 4.2		0.12 to 0.17		ISO 8256 - Method A	
Un-Instrumented Tensile Impact Clamps	7610.357	1, 2, 3 and 4	4	0.01 to	0.01 to 0.5		0.00039 to 0.02			
Ϋ́.	Catalog Number	Specimen Types			ecin ickn		Load Capacit	ty	Testing Standards	
				mm		in				
Tensile	7610.305	1, 2, 3 and 4	4	0.5 to 4.2	0	.020 to 0.17	Dependar Selected Force			
Instrumented Tensile Impact Clamps	7610.306	5		3.0 to 4.2	(0.12 to 0.17	Dependar Selected Force		ISO 8256 - Method A	
Instrun Imp	7610.307	1, 2, 3 and 4	4	0.01 to 0.5	0.0	00039 to 0.02	Dependar Selected Force		-	
	Catalog Number	Specimen Types		Specimen Thickness		Loa Capa		S	Testing tandards	
ors act						kN	Ibs			
Sens	7610.310	All		All		0.45	101	- 150.82	56 - Method A	
Force Sensors Tensile Impact	7610.311	All		All		2.2	495	100 02		
ЩЩ	Catalog Number	Description	I	Specimen Types			Specimen Thickness		Standards Testing	
						mm	ir	1		
_	7610.371	15 g Crosshe	ad	1, 2, 3 and	4	0.5 to 4.2	0.020 t	0.17		
3	7610.372	30 g Crosshe	ad	1, 2, 3 and	4	0.5 to 4.2	0.020 t	0.17		
	7610.373	60 g Crosshe	ad	1, 2, 3 and		0.5 to 4.2	0.020 t	0.17		
act Is	7610.374	120 g Crosshe	ead	1, 2, 3 and	4	0.5 to 4.2	0.020 t	0.17		
Fensile Impact Crossheads	7610.381	15 g Crosshe	ad	5		3.0 to 4.2	0.020 t	0.17	ISO 8256 -	
nsile ross	7610.382	30 g Crosshe	ad	5		3.0 to 4.2	0.020 t	0.17	Method A	
D D	7610.383	60 g Crosshe	ad	5		3.0 to 4.2	0.020 t	0.17		

120 g Crosshead

15 g Crosshead

30 g Crosshead

5

1, 2, 3 and 4

1, 2, 3 and 4

3.0 to 4.2


0.01 to 0.5

0.01 to 0.5

0.020 to 0.17

0.020 to 0.17


0.020 to 0.17



Instrumentation and Software

The addition of instrumentation to an impact system allows the engineer to "see" all types of information that was previously unknown, including incipient damage points and ductile-brittle transition zones. With instrumentation, the load on the specimen is continuously recorded as a function of time and/or specimen deflection prior to fracture. This gives a more complete representation of an impact than a single calculated value. Because failures originate at the weakest point and propagate from there, samples don't have to shatter to be considered failures. Depending on the requirements, failure can be defined by deformation, crack initiation, or complete fracture.





Section at a Glance	Page
Data Acquisition System	40
Visual IMPACT Software	41

Instrumentation and Software

Data Acquisition System


The CEAST DAS 64K is a state-of-the-art Data Acquisition System designed for impact testing instruments. Compatible with the full range of CEAST Impact Testing Systems, the CEAST 9000 Series Pendulum Machines and the CEAST 9300 Series Drop Towers, it's the key for instrumented impact testing. The DAS 64K also enables the data collection from instrumented tups or hammers on older models and non-CEAST impact machines.

The DAS 64K is the result of a complete re-design that enhances its versatility and testing efficiency. This significant step forward is also accomplished by the simultaneous evolution of Visual IMPACT, the dedicated software for instrument handling and data processing.

	Catalog Number	Description	Additional Information	Compatible Machines
1	7190.000	CEAST DAS 64k - High Speed Data Acquisition Unit	Up to 4 Channels	
	7191.000	CEAST DAS 64k - SC High Speed Data Acquisition Unit	Single Channel	
	7190.010	Strain Gauge Channel for DAS 64k	CEAST 9 CEAST 9	
	7190.020	Piezo Channel for DAS 64k	14 Bit Resolution, Up	CEAST 9340 CEAST 9350
	7190.030*	Voltage Channel for DAS 64k, 0 to +10V	to 2 MHz Sampling Frequency, and 65,536	02/01/0000
	7190.040*	Voltage Channel for DAS 64k, -10 to +10V	Points per Channel	
	7190.050*	4 to 20mA Channel for DAS 64k		
	7190.061	Cable set for Dynatup Retrofitting	To connect Dynatup tup to DAS 64k and 64k-SC Dynat Acquisiation Channels	

*To be used only with DAS 64k code 7190.000





Visual IMPACT Software

Visual IMPACT v.6.00 is a powerful software suite designed for impact testing. Developed within the CeastVIEW software platform, it brings together CEAST and Instron® experience of impact testing, providing a complete interface between the instruments and the end user. Developed for data processing, organization, and reporting, it is configured into common application areas with a full set of new features for customization.

Catalog Number	Description	Additional Information	Compatible Machines
2 0710.690.1	Visual IMPACT v.6.00 Un-Instrumented Pendulums	For Analysis of Pendulum Tests Conducted with Un-Instrumented Hammers	CEAST 9050
2 0710.690.2	Visual IMPACT v.6.00 Instrumented Pendulums	For Analysis of Pendulum Tests Conducted with Instrumented Hammers	CEAST 9050
2 0710.690.3	Visual IMPACT v.6.00 Instrumented Drop Towers	For Analysis of Tests Conducted with Instrumented Tups on Drop Towers	CEAST 9350 CEAST 9340 CEAST 9310 Dynatup Retrofitting



Specimen Preparation

Proper preparation of the specimen is a critical process for accurate material characterization. An appropriate preparation of the specimen, as well as an adequate notching procedure, effect the final test results, that generate reliable outcomes in the finished product performances. This is accomplished by several specimen preparation techniques, making them particularly suitable to select the most appropriate material and failure results analysis.

According to the requirements of the main international standards, Instron® offers an extensive range of notching, milling, and punching machines designed to prepare specimens from thin to thick samples, as well as from soft to hard samples and reinforced plastic materials.





Section at a Glance

Notching Machines	44
Manual and Motorized Notchvis	44
Automatic Notchvis	45 - 46
Punching Machines	47

Page

Notching Machines

Notching Machines are designed to notch specimens for impact resilience determinations according to Izod, Charpy, and Tensile Impact methods. These instruments use a linear knife cutting technique to avoid overheating and consequent stresses during the specimens notching operations. Therefore, they are able to guarantee an accurate notch preparation. Manual, motorized, and fully-automatic models are available to cover the different testing needs.

Manual and Motorized Models

The manual and motorized Notching Machines are designed to notch thermoplastic material specimens. A notch, with dimension according to the requirement of the main international standards, is obtained by means of a constant profile knife with an alternating linear movement. For high precision, a micro-metric head with digital display can be supplied to ensure a constant monitoring of the specimen notch.

	Catalog Number	Description
1	6897.000	CEAST Manual Notching Machine - Manually-Operated Notching Machine with Linear Movement of Cutting Knife
2	6898.000	CEAST Motorized Notching Machine - Notching Machine with Motorized Linear Movement of Cutting Knife

Catalog Number	Notch Radius	Testing Standards	Material
6530.042	0.25 ± 0.05 mm	ISO 179 A ISO 180 A ASTM D6110	Cobalt Steel
6530.045	0.25 ± 0.05 mm	ASTM D0110 ASTM D256 BS 2782-359 A	Tungsten Carbide
6530.043	1 ± 0.02 mm	ISO 179 B ISO 180 B ISO 8256 1	Cobalt Steel
6530.053	1 ± 0.02 mm	ASTM D256 D BS 2782-359 B	Tungsten Carbide
6530.055	0.1 ± 0.02 mm	ISO 179 C	Cobalt Steel
6530.063	0.1 ± 0.02 mm	ISO 179 C	Tungsten Carbide
6530.062	0.5 ± 0.05 mm	ASTM D256 D	Cobalt Steel
6530.061	0.5 ± 0.05 mm	ASTM D256 D	Tungsten Carbide
6530.041	2 ± 0.2 mm	BS 2782-359 C DIN 53453 C	Cobalt Steel
6530.049	2 ± 0.2 mm	BS 2782-359 C DIN 53453 C	Tungsten Carbide
6530.040	$0.8 \pm 0.1 \text{ mm}$	BS 2782-359 C DIN 53453 2	Cobalt Steel
6530.064	$0.8 \pm 0.1 \text{ mm}$	BS 2782-359 C DIN 53453 2	Tungsten Carbide



Automatic Model

The CEAST AN50 is designed for laboratories that need to perform a large number of impact tests. Up to 50 specimens can be notched in a single cycle with the key parameters stored for later use. The optional knife cooling system, double notch loader, and an adjustable cutting speed allow for consistent time savings and accurate notching operations at the same time.

	Catalog Number	Description
3	6899.000	CEAST AN50 - Microprocessor Controlled Unit to Notch a Set of Specimens and Optionally to Slice Their Ends
	6899.000C1	Basic Configuration - Without Cooling or Slicing Devices
	6899.000C2	Option for Knife Cooling Device - Based on an Adjustable Jet of Compressed Air
		Option for Knife Cooling and Slicing Devices - Knife Cooling Based on an Adjustable Jet of Compressed Air - Equipped with Two Circular Saws to Automatically Cut Both Ends of the Specimen to 80 or 63.5 mm

8

Specimen Loaders

Loaders are used to hold specimens before notching and can be used for holding dumbbell specimens that can be cut to the correct length when the optional slicing device is used.

Catalog Number	Description
6867.006	Specimen Loader for both Rectangular and "Dumbbell" Specimens
6867.005	Loader for Double Notching of Rectangular Specimens According to ISO 179-1, ISO 8256, and Equivalent Standards (size 4 × 10 × 80 mm)
6867.005	Loader for Double Notching of Rectangular Specimens According to BS 2782-359 and Equivalent Standards (size 50 × 6 mm)

Loaders for the CEAST AN50

Catalog Number	Notch Radius	Testing Standards	Material
6819.113	0.25 ± 0.05 mm	ISO 179 A ISO 180 A	Cobalt Steel
6819.100	0.25 ± 0.05 mm	ASTM D6110 ASTM D256 BS 2782-359 A	Tungsten Carbide
6819.119	1 ± 0.02 mm	ISO 179 B ISO 180 B	Cobalt Steel
6819.096	1 ± 0.02 mm	ISO 8256 1 ASTM D256 D BS 2782-359 B	Tungsten Carbide
6819.130	0.1 ± 0.02 mm	ISO 179 C	Cobalt Steel
6819.097	0.1 ± 0.02 mm	ISO 179 C	Tungsten Carbide
6819.314	0.5 ± 0.05 mm	ASTM D256 D	Cobalt Steel
6819.313	0.5 ± 0.05 mm	ASTM D256 D	Tungsten Carbide
6819.115	2 ± 0.02 mm	BS 2782-359 C DIN 53453 C	Cobalt Steel
6819.094	2 ± 0.02 mm	BS 2782-359 C DIN 53453 C	Tungsten Carbide
6819.114	0.8 ± 0.01 mm	BS 2782-359 C DIN 53453 2	Cobalt Steel

Punching Machines

Clamping These machines are developed to obtain specimens by punching, using hollow dies of different sizes and contours. Several hundreds of dies can be created by interchangeable socket punches with different profiles and sizes according to the standards and to the customer needs. Dies are made of steel with hand-finished cutting edges and can be provided with the ejector for easily removing the specimen after punching.



Pneumatic Hollow Die Punch



Manual Hollow Die Punch

Catalog Number	Shape	Dime	nsions	Testing Standards
		mm	in	
8160.020	Rectangular	80 × 10	3.15 × 0.4	ISO 75-2, ISO 178 ISO 179-1, 179-2 Type 1 ISO 180, ISO 8256 Type 1
8083.020	Rectangular	127 × 12.7	5 × 0.5	ASTM D648, ASTM D790 ASTM D6110
8246.020	Rectangular	63.5 × 12.7	2.5 × 0.5	ASTM D256
8057.020	Dumb-bell Single Radius	80 × 15 × 10	3.15 × 0.6 × 0.4	ISO 8256 Type 3
8058.020	Dumb-bell Single Radius	60 × 10 × 3	2.4 × 0.4 × 0.12	ISO 8256 Type 4
8369.020	-	80 × 15 × 5	3.15 × 0.6 × 0.2	ISO 8256 Type 5
8017.020	Circular	60	2.4	ISO 6603
8806.020	Square	60 × 60	2.4 × 2.4	ISO 6603
8085.020	Circular	80	3.15	ISO 7765

Appendix

Standards

ISO

ISO 6603-1,-2, p17 ISO 7765-1,-2, p17 ISO 8256 A, p20, 36, 37 ISO 179-1,-2, p24, 28, 29, 44, 45, 4 ISO 179/A, B, p44, 46 ISO 180/A, B, p25, 32, 33, 44, 46 ISO 148, p31 ISO 8256,-1, p45, 46 ISO 9854-1, p35

DIN

DIN 53453/C, -2, p28, 29, 44, 46 DIN 53753, p28, 29 DIN 50115, p31

ASTM

ASTM D5628, p17 ASTM D3763, p17 ASTM D1709, p17 ASTM D7136/M, p18 ASTM D2444, p19 ASTM D6110, p24, 30, 44, 46 ASTM E23, p24, 25, 31 ASTM D256/D, p25, 32, 33, 44,46 ASTM D4812, p32, 33, 35 Boeing BSS 7260, p18

Other

Montell Method MA 17238, p17 Airbus AITM 1.0010, p18 Boeing BSS 7260, p18 SACMA 2R-94, p18 PR EN 6038, p18 BS 2782-359/A, B, C p28, 29, 44, 45, 46



Notes



www.instron.com

Worldwide Headquarters 825 University Avenue, Norwood, MA 02062-2643 USA +1 800 564 8378 | +1 781 575 5000

European Headquarters Coronation Road, High Wycombe, Bucks, HP12 3SY UK +44 1494 464646

CEAST Headquarters

Via Airauda 12, 10044 Pianezza TO, Italy +39 011 9685 511

